LEGENDARY SERIES™

FLOORING SORINEX® | BUILT ON itsTRU TECHNOLOGY

Rubber Flooring Maintenance Guidelines

www.sorinex.com

Composition Rubber Flooring -

Daily Maintenance

WATCH VIDEO HERE

Directions

Dry

- Dust mop, sweep or vacuum all abrasive debris from your floor

Wet

- In a 1 gallon pump sprayer, add 3 ounces E-Cleaner to one-gallon cool water. Spray dirty areas and use a cloth or microfiber mop. Let dry

Rubber Flooring -

Restorative / Routine Cleaning

WATCH VIDEO HERE

Directions

- Dust mop, sweep or vacuum all abrasive debris from your floor
- For restorative cleaning, dilute E-Cleaner to 3 ounces E-Cleaner to one-gallon cool water in a pump sprayer
- Apply cleaning solution (E-Cleaner or E-Strip with the appropriate water dilution) to your floor using your pump sprayer and allow the solution to stand for 5 minutes. Apply cleaning solution in manageable sized areas so that it does not dry
- Use a 1.5 HP (175 RPM) rotary floor machine with a red stripping pad to agitate the solution.
- Use a wet-vac with squeegee head or a walk-behind floor scrubber to pick up the cleaning solution.
- Rinse with clean water using a mop and allow to dry

Equipment



- 1.5 HP (175 RPM) Rotary Floor Machine with Red or Black Stripping Pad
- Sizes: 13 inch, 17 inch, 20 inch
- Used together to agitate E-Strip Floor Stripper



- Wet-vac with squeegee accessory
- Used to pick up stripper solution

FOR CONDITIONING / DEEP CLEANING WATCH VIDEO HERE